

Technical Bulletin

Date Released: 07-20-2011

Tracking Number: TBACTH-001

Model / Part Number: ACTH / ACTH11


Re: Thermostat display function

Details: The default settings of the ACTH & ACTH11 display functions are:


1. Display will show desired temperature setting for 5 seconds after adjustment.
2. Display will then show current ambient temperature for 30 seconds.
3. Display will then turn OFF.
4. Display will turn ON again once temperature control, ON/OFF or fan speed control is adjusted.

Notes:

It is possible to change the display to remain always ON and showing the ambient temperature rather than turn OFF after 30 seconds. This can be done by changing DIP switch #1 from its default setting of OFF to ON. The DIP switch is accessible once the front cover is removed.



Default DIP settings



Adjusted DIP settings for display always ON